
## NOTE: Tools not furnished with pump.

## Tools for all Pumps:

- (1) Safety Glasses
- (1) 9/16" Combination Wrench
- (1) 3/4" Combination Wrench
- (1) 18" Pipe Wrench
- (1) Pliers
- (1) 3/32", 5/32" & 5/15" Hex Head Wrench (Allen Wrench)

## 5. DIRECTION OF ROTATION



DIRECTION OF ROTATION FOR HIGH DRIVE & LOW DRIVE PUMP CONFIGURATIONS Figure 5.1